

PN EVABKPK1

▲ WARNING

Use strictly in accordance with instructions, labels and limitations pertaining to the EVA Series respirator.

1. The EVA Series respirator does not supply oxygen. Use only in adequately ventilated areas containing at least 19.5% oxygen.
 2. Do not use when concentrations of contaminants are immediately dangerous to life or health (IDLH). This term is defined in 29CFR 1910.134 (b).
 3. Do not use these respirators for respiratory protection during abrasive blasting or clean up.
 4. Do not use in circumstances where the airborne concentration level of contaminant exceeds maximum use concentration for this type of respirator as established by regulatory standards.
 5. Leave area immediately if:
 - Breathing becomes difficult
 - Dizziness or other distress occurs
 - You taste or smell the contaminant
 - Unit becomes damaged
 - Battery alarm activates
 - Low Flow alarm activates
 6. This apparatus must not be worn with the blower unit switched off. If the blower is switched off, a rapid build-up of carbon dioxide and depletion of oxygen may occur, which could result in death or serious injury.
 7. Never alter or modify this respirator. Use only Bullard NIOSH-approved EVA Series components and replacement parts for this respirator.
 8. This device is not immune to highly powered RFI/EMI emissions.
- Failure to follow these warnings could result in death or serious injury.

Installing the Blower Unit onto the Back Pack

1. Remove the belt from the blower:
 - a. Lay the blower with the filter side down
 - b. Orient the lever locks as shown in Figures 1-2
 - c. Remove the belt



Figure 1



Figure 2



Figure 3

2. Install the back pack:
 - a. Lay the Back Pack over the lever locks aligning the lever locks with the corresponding slots in the back pack
 - b. Rotate the lever locks until they are oriented as shown in Figure 3



Preparation for Donning

1. Install the following onto the blower unit per the EVA/EVAHL User Instructions:
 - a. Battery
 - b. Filter
 - c. Breathing Tube
 - d. Hood
2. Turn the blower unit on



Figure 4

Donning the Back Pack with Blower

1. Slide one arm into the corresponding arm loop (Figure 4)
2. Repeat on other arm
3. Adjust the vertical slides until comfortable (Figure 5)
4. Buckle the cross strap (Figure 6)



Figure 5



Note: Many find this to be most comfortable very high on the chest

5. Adjust cross straps until comfortable (Figure 7)
6. Excess strapping may be cut and removed if desired



Figure 6



Figure 7

Americas:

Bullard
1898 Safety Way
Cynthiana, KY 41031-9303 • USA
Toll-free within USA: 877-BULLARD (285-5273)
Tel: +1-859-234-6616
Fax: +1-859-234-8987

Europe:

Bullard GmbH
Lilienthalstrasse 12
53424 Remagen • Germany
Tel: +49-2642 999980
Fax: +49-2642 9999829

Asia-Pacific:

Bullard Asia Pacific Pte. Ltd.
LHK Building
701, Sims Drive, #04-03
Singapore 387383
Tel: +65-6745-0556
Fax: +65-6745-5176

